

Hydro Wine Watering System



We wanted to provide you with some tips for the Self Watering Planter Spikes that you purchased.

1. Soak the stakes in water prior to use

We recommend doing this for 1-2 hours prior to placing it in your planter pot as terracotta can be sensitive when dry for a long time.

2. Dig a hole before placing the spike in your planter

Depending on your plant and the soil, the spike may not be able to push through the top layer on its own. Dig a hole deep enough to have the spike and the bottle secure in your planter pot.

3. Fill a long neck wine bottle with water

Longer neck bottles allow for it to settle further in the spike making it more stable when flipped upside down. Make sure it is cleaned out first!

4. Place stake on top of the filled bottle

Make sure it securely fits on the bottle before planting!

5. Turn the bottle over carefully with the stake on top

Place the bottle in the hole you dug making sure to keep the bottle straight upright. You want most of the stake in the soil for best results.

6. Check the bottle occasionally for water level

You don't have to take the stake out of the soil to refill the bottle.

We appreciate your purchase and hope you and your plants enjoy!